


FORSTHOFF

Plastic Welding Equipment Forsthoff Hot Air Welders



Forplast-P Overlap Welder Code : 2401101

The FORPLAST-P automatic welding machine is a powerful tool for welding truck tarpaulins, tents and awning materials. It produces overlap welds of either 20* or 45 mm and can also be supplied as or converted to an automatic welding machine for webbing tapes. The heating capacity of 3300 W, 230V AC is electronically variable between 20 and 700 °C to suit various materials. The welding machine starts automatically when the welding head is moved into position. An additional cold setting cools the blower after use without having to alter the preset temperature. Variable speed from 0–19 m/min. ensures an optimum welding result. 3-point surface contact of the machine ensures that pressure is evenly distributed over the tarpaulin. (*20mm as standard) Now available with hem welding kit.



Forplast-B Tape Welder Code : 2101086

The FORPLAST-B automatic welding machine is a powerful machine for 50 mm webbing tapes. The automatic hot air welding machine has a heating capacity of 4000 W, 230V AC and is electronically variable up to 700 °C. The drive unit features a powerful motor and heavy-duty housing for maximum speed and pressure. The machine starts automatically when the welding head is moved into position. The machine housing is supported at three points to compensate for any unevenness of surface to be welded. The speed is infinitely variable to suit different materials.



Forplast-F Floor Welder Code : 2101200

The FORPLAST-F automatic welding machine is suitable for welding both PVC floor coverings as well as fusion welding and sealing of linoleum. The heating capacity of 3000 W, 230V AC is electronically variable between 20 and 700 °C. The machine features infinite speed variation from 0–19 m/min. to suit various materials. Precise uncoiling of the welding wire is ensured by means of a high-temperature resistant coating on the pressure roller and wire guide. The universal uncoiler fits all standard wire spools. The machine is fully equipped for welding and also features an automatic cut-out facility. The machine starts automatically when the welding head is moved into position. 3-point surface contact of the machine housing ensures precise movement.

Watch video www.forsthoffwelding.com



Fusion Hire Services Pty Ltd
11-15 Martha Street Seaford, Victoria 3198 Australia
Ph 03 8770 5770 Fax 03 8770 5771
info@fhs.com.au

ABN 80 075 195 292 ACN 075 195 292

www.fhs.com.au